

Lancer cette commande au demarrage du raspberry

1. -Ouvrez le fichier rc.local :
2. -sudo nano /etc/rc.local
3. -Insérez votre script ou service juste avant la ligne «exit 0» De cette manière :

```
#!/etc/rc.local 330/330 100%
#
# rc.local
#
# This script is executed at the end of each multiuser runlevel.
# Make sure that the script will "exit 0" on success or any other
# value on error.
#
# In order to enable or disable this script just change the execution
# bits.
#
# By default this script does nothing.
#
# Print the IP address
IP=$(hostname -I) || true
if [ "$IP" ]; then
    printf "My IP address is %s\n" "$IP"
fi
#demarre les instances nodered : 1881,1884,1885,1886,1887,1888,1889,1890,1891,1892
/home/pi/.demonodered.sh
exit 0
```

Enregistrez et quittez (CTRL+X)

From:

<http://chanterie37.fr/fablab37110/> - Castel'Lab le Fablab MJC de Château-Renault

Permanent link:

<http://chanterie37.fr/fablab37110/doku.php?id=start:rasberry:nodered:dem&rev=1698680470>

Last update: **2023/10/30 16:41**

