

Date et heure dans Node red

Avec le noeud Date/Time Formater

Il faut dans le menu " Gerer la palette" installer ==> **node-red-contrib-moment**



Dans node-red , mettre les noeuds suivant :



Le noeud "Horodatage"

Last update:

2024/01/23 start:esp32:nodered:heure:nr <https://chanterie37.fr/fablab37110/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004537>
11:08

Modifier le noeud inject

Supprimer Annuler Terminer

Propriétés

Nom: Nom

msg.payload = horodatage

msg.topic = 0

+ Ajouter Injecter maintenant

Injecter une fois après 0.1 secondes, puis

Répéter: intervalle

chaque 1 secondes

le noeud "Date/Time Formatter" pour la date

Modifier le noeud Date/Time Formatter

Supprimer Annuler Terminer

Propriétés

← Input from horodatage

Input Timezone Europe/Paris

Adjustment + 0 Hours

Output Format DD - MM - YYYY

🇫🇷 Locale fr-FR

Output Timezone Europe/Paris

→ Output to msg. mytime

📄 Topic Topic

🏷️ Name Format date

See the info sidebar for formatting details.
Use locale and format to change string output.
See the info sidebar for several warnings about inputting strings.

From:
<https://chanterie37.fr/fablab37110/> - **Castel'Lab le Fablab MJC de Château-Renault**

Permanent link:
<https://chanterie37.fr/fablab37110/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004537>

Last update: **2024/01/23 11:08**

