

Date et heure dans Node red

Avec le noeud Date/Time Formater

Il faut dans le menu " Gerer la palette" installer ==> **node-red-contrib-moment**



Dans node-red , mettre les noeuds suivant :



Le noeud "Horodatage"

The screenshot shows a Node-RED configuration window titled "Modifier le noeud inject". At the top, there are three buttons: "Supprimer", "Annuler", and "Terminer". Below this is a "Propriétés" section with a search bar and icons for settings, save, and refresh. The main configuration area includes a "Nom" field with the value "Nom". Below that, there are two message properties: "msg. payload" set to "horodatage" and "msg. topic" set to "a_z". At the bottom, there are controls for injection timing: a checkbox for "Injecter une fois après 0.1 secondes, puis", a "Répéter" section with a dropdown for "intervalle" and a spinner for "chaque 1" seconds, and an "Injecter maintenant" button.

le noeud "Date/Time Formatter" pour la date

Modifier le noeud Date/Time Formatter

Supprimer Annuler Terminer

Propriétés

← Input from horodatage

Input Timezone Europe/Paris

Adjustment + 0 Hours

Output Format DD - MM - YYYY

🇫🇷 Locale fr-FR

Output Timezone Europe/Paris

→ Output to msg. mytime

📄 Topic Topic

🏷️ Name Format date

See the info sidebar for formatting details.
Use locale and format to change string output.
See the info sidebar for several warnings about inputting strings.

From:
<https://chanterie37.fr/fablab37110/> - **Castel'Lab le Fablab MJC de Château-Renault**

Permanent link:
<https://chanterie37.fr/fablab37110/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004552>

Last update: **2024/01/23 11:09**

