

# Date et heure dans Node red

## Avec le noeud Date/Time Formater

Il faut dans le menu " Gerer la palette" installer ==> **node-red-contrib-moment**




Dans node-red , mettre les noeuds suivant :



Le noeud "Horodatage"

The screenshot shows a Node-RED configuration window for an inject node. At the top, there are three buttons: 'Supprimer', 'Annuler', and 'Terminer'. Below is a 'Propriétés' section with a search bar and icons for settings, help, and refresh. The main configuration area includes a 'Nom' field with the value 'Nom'. Below this, there are two rows of configuration for message properties: 'msg.payload' is set to 'horodatage' and 'msg.topic' is set to 'a\_z'. At the bottom, there are options for injection timing: 'Injecter une fois après 0.1 secondes, puis' (unchecked), and 'Répéter' with an interval of 'intervalle' and a frequency of 'chaque 1 secondes'.

le noeud "Date/Time Formatter" pour la date ==> Input From = Horodatage Output format = DD - MM - YYYY et Output to = msg.mytime



le noeud "Date/Time Formatter" pour l'heure ==> Input From = Horodatage Output format = h - m - s ( en minuscule )et Output to = msg.mytime

From:  
<https://chanterie37.fr/fablab37110/> - Castel'Lab le Fablab MJC de Château-Renault

Permanent link:  
<https://chanterie37.fr/fablab37110/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004859>

Last update: 2024/01/23 11:14

