

# Date et heure dans Node red

## Avec le noeud Date/Time Formater

Il faut dans le menu " Gerer la palette" installer ==> **node-red-contrib-moment**




Dans node-red , mettre les noeuds suivant :



Le noeud "Horodatage"

The screenshot shows a Node-RED configuration window for an inject node. At the top, there are three buttons: 'Supprimer', 'Annuler', and 'Terminer'. Below this is a 'Propriétés' section with a search bar and three icons (gear, document, refresh). The main configuration area includes a 'Nom' field with the value 'Nom'. Below that, there are two rows of configuration for message properties: 'msg. payload' is set to 'horodatage' and 'msg. topic' is set to 'a\_z'. At the bottom, there are controls for injection timing: a checkbox for 'Injecter une fois après 0.1 secondes, puis', a 'Répéter' section with a dropdown for 'intervalle' and a spinner for 'chaque 1 secondes', and buttons for 'Ajouter' and 'Injecter maintenant'.




le noeud "Date/Time Formatter" pour la date ==> Input From = Horodatage Output format = DD - MM - YYYY et Output to = msg.mytime



le noeud "Date/Time Formatter" pour l'heure ==> Input From = Horodatage Output format = h - m - s ( en minuscule ) et Output to = msg.mytime

### Modifier le noeud Date/Time Formatter

Supprimer Annuler Terminer

**Propriétés**   

← Input from ▼ horodatage

Input Timezone Europe/Paris

Adjustment + ▼ 0 Hours ▼

Output Format h - m - s

🚩 Locale fr-FR

Output Timezone Europe/Paris

➔ Output to ▼ msg. mytime

☰ Topic Topic

🔑 Name Format heures

See the info sidebar for formatting details.  
Use locale and format to change string output.  
See the info sidebar for several warnings about inputting strings.

From:

<https://chanterie37.fr/fablab37110/> - **Castel'Lab le Fablab MJC de Château-Renault**

Permanent link:

<https://chanterie37.fr/fablab37110/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004937>

Last update: **2024/01/23 11:15**

