

Date et heure dans Node red

Avec le noeud Date/Time Formater

Il faut dans le menu " Gerer la palette" installer ==> **node-red-contrib-moment**




Dans node-red , mettre les noeuds suivant :



Le noeud "Horodatage"

The screenshot shows a configuration window for a Node-RED 'Inject' node. At the top, there are three buttons: 'Supprimer', 'Annuler', and 'Terminer'. Below this is a 'Propriétés' section with a search bar and three icons (gear, document, refresh). The main configuration area includes a 'Nom' field with the value 'Nom'. Below that, there are two rows of configuration for message properties: 'msg.payload' is set to 'horodatage' and 'msg.topic' is set to 'a_z'. At the bottom, there are options for injection timing: 'Injecter une fois après 0.1 secondes, puis' (unchecked), and a 'Répéter' section with 'intervalle' set to 'intervalle' and 'chaque 1 secondes'.

le noeud "Date/Time Formatter" pour la date ==> Input From = Horodatage Output format = DD - MM - YYYY et Output to = msg.mytime



le noeud "Date/Time Formatter" pour l'heure ==> Input From = Horodatage Output format = h - m - s (en minuscule) et Output to = msg.mytime

Modifier le noeud Date/Time Formatter

Supprimer Annuler Terminer

Propriétés

← Input from horodatage

Input Timezone Europe/Paris

Adjustment + 0 Hours

Output Format h - m - s

Locale fr-FR

Output Timezone Europe/Paris

→ Output to msg. mytime

Topic Topic

Name Format heures

See the info sidebar for formatting details.
Use locale and format to change string output.
See the info sidebar for several warnings about inputting strings.

From:
<https://chanterie37.fr/fablab37110/> - Castel'Lab le Fablab MJC de Château-Renault

Permanent link:
<https://chanterie37.fr/fablab37110/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004969>

Last update: 2024/01/23 11:16

